


# WARNING!

For proper venting be sure to mount your charger vertically to a wall. The unit may overheat if set flat on a counter. With all six stations in operation the case may become very hot to the touch when vertical ventilation is inhibited.



# WARNING!

For proper venting be sure to mount your charger vertically to a wall. The unit may overheat if set flat on a counter. With all six stations in operation the case may become very hot to the touch when vertical ventilation is inhibited.

